

## Floor bathtub mixer instruction

parts list as follow. contact with seller. Spare Please inspection all spare if any problem, please parts list when you open box,

<b>}</b>	Screw tool	<u> </u>
<b>,</b>	Instruction	10
<b>-</b>	Glove	9
} <b>-</b>	shower hose	∞
<b>}</b>	Hand shower	-7
4	Expansion Screw	6
<b></b>	N-box	ూ
2	Water pipe	4
<b>}</b>	Panel	ယ
<b>}</b>	Body Pipe	2
<b>1—</b>	Control body	<u> </u>
QTY	Product Description	No










9. Fix pipe in N-box, adjust position,


shower.


10. Fix shower hose and hand



























Fix by M6 expansion Screw. 2. Adjust level by gradiometer.

NOTICE:








5. Take spare parts, cover, test parts and gradiometer.

4. Clean up.

joint. Prevent no leakage. 3. Jointing hot and cold water







6. Connect body by H8 screw tool.

7. Fix panel by N4 screw.

